

Jumbo HBC handlebar or BCM perch mount

Separate Units Fit 1" or 7/8", 1 1/4", 1 1/2" Bars

The Jumbo Handlebar or Perch Mount Clock fits on 1" bars (or 7/8" bars utilizing the included clear plastic spacer). The Jumbo Handlebar 1 1/4" Clock fits on 1 1/4" bars. The Jumbo Handlebar 1 1/2" Clock fits on 1 1/2" bars. The perch mount will fit most Harley control housings and metrics (may require metric spacer not included) *Please note how the unit is assembled so you can re-assemble it properly on the bar.*

The Jumbo Handlebar Mount comes with a clock, one set screw for clock retention, one clear plastic spacer, one extra screw for assembly, one hex head wrench and billet mount. (1 1/4" & 1 1/2" units do not contain clear plastic spacers for alt. bar size) The Jumbo Perch Mount comes with a clock, one set screw for clock retention, one hex head wrench and billet mount.

- 1) Carefully remove the item from its package.
- 2) To remove the clock, locate the set screw at the bottom of the Jumbo mount on the bezel, loosen it counter clockwise and the clock will be able to be removed. Make sure that the clock does not fall and become damaged. *****DO NOT OVER TIGHTEN SET SCREW*****

Handlebar Install.

- 3) Remove the two rear screws, separating the two mount halves.
- 4) Place the handlebar mount halves in the position of your choice on the bars (keep away from curves or areas the bar may not be a consistent thickness), re-insert the supplied screws and tighten gently and evenly (for the mount to tighten properly there should be a small gap between the two halves, no bar is the same so the gap will vary - do not over-tighten).

Perch Mount Install.

- 3) For control unit installation remove one bolt from the top or bottom of the handlebar control (perch) clamp.
- 4) Place the mount in position and re-insert the bolt and tighten.
- 5) Loosen the hex screw on the head unit, move it into position desired and tighten hex screw to lock head in place.
- 6) After setting the time per instructions in General Care Section, install the clock into the holder/mount all the way as per instructions in the General Care section of these instructions.

Note: You may use blue Ithread lock on the screws to stop them from becoming loose.



↑
**Set
Screw**

ALL RETURNS MUST BE PACKED TO ELIMINATE DAMAGE DAMAGED RETURN ITEMS WILL NOT BE ACCEPTED OR CREDITED

If returning an item after obtaining an authorization please send it to:

Marlin's Genuine Accessories 5139 Juniper Dr. Commerce Twp., MI 48382

Make sure to return items using a trackable service method with adequate insurance.

Marlin's will not be responsible for lost or damaged returns.

**Please contact Marlin's directly for parts
or service before returning item to dealer**



Enjoy your Marlin's Product

Technical support: 248-683-1536
www.marlinclocks.com

General Care, Installation and Operation Instructions

IMPORTANT - READ THIS!

ALL RETURNS MUST BE PACKED TO ELIMINATE DAMAGE - DAMAGED RETURNS WILL NOT BE ACCEPTED
DO NOT push on the glass face when inserting the clock into the holder / mount. Push on the chrome ring or bezel to insert. Make sure clock is inserted all the way into holder / mount before riding and set screw is secure or loss and / or damage may result.

The holder/mount and bezel can be polished and cared for with a quality chrome polish.
Your new clock is waterproof, shock resistant and the numbers may glow in the dark if so equipped. *The face must be exposed to a light source before you ride to charge and activate the glow in the dark feature.*

TO REMOVE YOUR CLOCK FROM THE HOLDER/MOUNT:

Locate the set screw at the bottom of the Jumbo mount on the bezel, loosen it counter clockwise and the clock or thermometer insert will be able to be removed.

SETTING THE TIME: The crown to adjust the time is located on the side of the clock housing (inside the mount, you must remove the clock from the mount to access the crown at the 3 o'clock position. To set the time, carefully pull the crown out until it clicks and turn it until the desired time is show. Push crown back in to the normal position to restart clock.

BATTERY REPLACEMENT: CAUTION: DO NOT LIFT THE MOVEMENT OUT OF THE CASE

When the clock loses time or stops the battery is due for replacement. The battery is accessible from the backside of the clock. Our clocks are manufactured with a screw on/off back cover. You may buy a back removal tool from us or use a needle nose pliers to easily remove and replace the back cover. A jeweler or watch band shop will also have a tool to remove the backing of the clock. The battery is retained in position by a tiny metal plate. Move the plate sideways gently to remove battery. Be sure when replacing the battery to use the same number or equivalent button cell (#377), with positive pole (+) facing outward. Make sure that it is retained securely in position by the metal plate. Replace cover making sure the O ring is properly in position and will form a satisfactory seal. Your Clock will not require you to open it prior to a battery replacement.

No other serviceable parts.

TO RE-INSERT YOUR CLOCK OR THERMOMETER INTO THE HOLDER/MOUNT:

Locate the set screw at the bottom of the Jumbo mount on the bezel, loosen it counter clockwise to allow the clock head to insert freely into the mount. Rotate the clock in the position you like and push it in place making sure there is no gap between the clock and the Jumbo mount so that the unit is firmly in place. Turn the set screw clockwise to firmly hold the clock head in place.

*****DO NOT OVER TIGHTEN SET SCREW*****

Be careful not to position the clock so you will tighten the set screw on top of the clock setting crown at the 3 o'clock position as it will damage it.

Note: You may use blue Ithread lock on the screws to stop them from becoming loose.